



FEASYCOM

FSC-BT100X

Sink Programming User Guide

Version 3.7



Copyright © 2013-2017 Feasycom Technology Co., Ltd. All Rights Reserved.

Revision History

Version	Data	Notes	Author
1.0	2015/10/10	First Release	Tony
2.0	2016/05/20	Add commands	Navy
3.0	2017/11/13	Add A2DP Source profiles	Navy
3.1	2018/01/25	Add commands	Navy
3.2	2018/08/31	Update Commands	Navy
3.3	2018/12/21	Add commands	Navy
3.4	2019/08/23	Add commands	Carfei
3.5	2019/08/29	Add commands	Carfer
3.6	2019/10/23	Add TWS command	Navy
3.7	2020/07/20	Add commans	Navy

Contact Us:

Shenzhen Feasycom Technology Co., Ltd

Web: www.feasycom.com

Email: support@feasycom.com

Tel: +86-755-27924639,+86-755-23062695

Address: Room 2004-2005,20th Floor, Huichao Technology Building,
Jinhai Road, Xixiang, Baoan District, Shenzhen,518100, China.

Contents

1. Introduction.....	6
1.1 Terms.....	6
1.2 Hardware Interface.....	6
1.3 Supported Bluetooth Profile	6
1.4 Command Format.....	6
1.5 Indication Format.....	7
1.6 Module Default Settings	7
2.Command Table	8
2.1 General Commands	8
2.1.1 AT Command Test.....	8
2.1.2 Bluetooth Profile Selection <auto reboot>	8
2.1.3 Read Firmware Version	9
2.1.4 Read BR/EDR MAC Address.....	9
2.1.5 Read BLE MAC Address	10
2.1.6 Read/Write BR/EDR Local Name	10
2.1.7 Read/Write BLE Local Name	10
2.1.8 Read/Write BLE Random Address Configuration <need reboot>	11
2.1.9 Read/Write UART Baudrate	11
2.1.10 Read/Write Pin Code	11
2.1.11 Turn On/Off Secure Simple Pairing <need reboot>	12
2.1.12 Read/Write Class Of Device <need reboot>	12
2.1.13 Read/Clear Paired Record	12
2.1.14 Turn On/Off Throughput Mode <need reboot>	13
2.1.15 Read Module States.....	13
2.1.16 Turn On/Off Power On Auto Reconnect <need reboot>	14
2.1.17 Scan Nearby Devices	14
2.1.18 Speaker Volume Setting.....	14
2.1.19 I2S/PCM Format Configuration <need reboot>	15
2.1.20 I2S Channel Setting< need reboot >.....	15
2.1.21 Release All Connections.....	16
2.1.22 Soft Reboot.....	16
2.1.23 Restore Factory Settings.....	16
2.1.24 Enable Module.....	16
2.1.25 Enter Pairing Mode	17
2.1.26 Enable Print Log.....	17
2.1.27 Audio Active PIO Delay Time Configuration	17
2.1.28 LineIn Configuration <need reboot>	17
2.2 HFP Commands	18
2.2.1 Read HFP State.....	18
2.2.2 Establish HFP Connection	18
2.2.3 Release HFP Connection.....	18
2.2.4 Dial/Redial Phone Number.....	19

2.2.5 Send DTMF code	19
2.2.6 Pick Up Incoming Call.....	19
2.2.7 Reject/Hung up Call	19
2.2.8 Transfer Voice Audio	20
2.2.9 Mute Mic	20
2.3.0 Start/Stop Voice Recognition of Remote Device.....	20
2.3 A2DP/AVRCP Commands.....	20
2.3.1 Read A2DP State.....	20
2.3.2 Establish A2DP Connection	21
2.3.3 Release A2DP Connection	21
2.3.4 Read A2DP Decoder	21
2.3.5 Read/Write AVRCP Configuration.....	22
2.3.6 Track Play/Pause.....	22
2.3.7 Track Play.....	22
2.3.8 Track Pause.....	23
2.3.9 Track Stop	23
2.3.10 Track Forward	23
2.3.11 Track Backward.....	23
2.3.12 Track FastForward	23
2.3.13 Track Rewind	24
2.4 TWS Commands.....	24
2.4.1 Read TWS State.....	24
2.4.2 TWS Configuration <i><need reboot></i>	24
2.4.3 Pair TWS Device	25
2.4.4 Read/Clear TWS Paired Record.....	25
2.4.5 Release TWS Connection	25
2.5 Phonebook Access Commands	26
2.5.1 Download Phonebook	26
2.6 Bluetooth Serial Commands (BR/EDR SPP).....	26
2.6.1 Read SPP State	26
2.6.2 Establish SPP Connection	26
2.6.3 Release SPP Connection	27
2.6.4 Send Data Via SPP.....	27
2.7 Bluetooth Serial Commands (LE GATT)	27
2.7.1 Read GATT State.....	27
2.7.2 Release GATT Connection.....	27
2.7.3 Send Data Via GATT	28
3. Indication Table	28
3.1 General Indications	28
3.1.1 Device State	28
3.1.2 Scan Result.....	28
3.1.3 Paired Success.....	29
3.2 HFP Indications	29
3.2.1 HFP State	29



3.2.2 HFP Device Information	30
3.2.3 Incoming/Outgoing Call Number	30
3.2.4 Incoming/Outgoing Call Name.....	30
3.2.5 HFP Voice Audio State	30
3.2.6 HFP Device Network Signal Strength.....	31
3.2.7 HFP Device Network Operator Selection	31
3.2.8 HFP Device Roaming State	31
3.2.9 HFP Device Battery Level.....	31
3.3 A2DP/AVRCP Indications.....	31
3.3.1 A2DP State	31
3.3.2 A2DP Device Information	32
3.3.3 AVRCP State.....	32
3.3.4 Media Player State.....	32
3.3.5 Media Player Play Progress.....	32
3.3.6 Media Track Information	33
3.4 Phonebook Access Indications.....	33
3.4.1 PBAPC State.....	33
3.4.2 PB Entries Of Remote Devices.....	33
3.4.3 Received Phonebook Data.....	34
3.5 Bluetooth Serial Indications.....	35
3.5.1 SPP State	35
3.5.2 GATT State.....	35
3.5.3 SPP Device Information.....	35
3.5.4 GATT Device Information.....	35
3.5.5 SPP Received Data.....	35
3.5.6 GATT Received Data	36
3.6 GPIO Indications	36
3.6.1 LED Pin	36
3.6.2 State Pin	36
4.Example Message Sequence Charts.....	37
4.1MSC for profiles initializing and device scanning	37
4.2MSC for profiles connection and basic operations	38
4.3MSC for Phonebook/Contact photo downloading.....	39

1. Introduction

This specification presents design guidelines for software engineers that use FSC-BT100X series modules for Bluetooth requirements.

1.1 Terms

Throughout this specification:

- {} : Content between {...} is optional
- << : Content behind << represents a *COMMAND* sent from Host to Module
- >> : Content behind >> represents a *RESPONSE* sent from Module to Host

1.2 Hardware Interface

- GPIO
- PWM
- UART
- I2C Master/Slave
- I2S Master/Slave
- Analog Input/Output

1.3 Supported Bluetooth Profile

- SPP (Serial Port Profile)
- GATT Server (Generic Attribute Profile)
- GATT Client (Generic Attribute Profile)
- HFP Sink (Hands-Free Profile)
- A2DP Sink (Advanced Audio Distribution Profile)
- AVRCP Controller (Audio/Video remote controller Profile)
- AVRCP Target (Audio/Video remote controller Profile)
- HID Keyboard (Human Interface Profile)
- PBAP Server (Phonebook Access Profile)

1.4 Command Format

AT+ Command {=Param1{, Param2{, Param3...}}} <CR><LF>

- All commands start with "AT", end with <CR><LF>
- <CR> stands for "carriage return", corresponding hex is 0x0D

- <LF> stands for "line feed", corresponding hex is 0x0A
- If command has parameter, parameter keep behind "="
- If command has multiple parameters, parameter must be separated by ","
- If command has response, response start with <CR><LF>, end with <CR><LF>
- Module will always report command's execution result using "OK" for success or "ERROR" for failure

e.g.

1. Read module's BR/EDR local name


```
<< AT+NAME
>> +NAME=Feasycom
>> OK
```
2. Pick up an incoming call when no call incoming actually


```
<< AT+HFPANSW
>> ERROR
```

1.5 Indication Format

<CR><LF>+ Indication {=Param1{, Param2{, Param3...}}} <CR><LF>

- All indications start with <CR><LF>, end with <CR><LF>
- If indication has parameter, parameter keep behind "="
- If indication has multiple parameters, parameter must be separated by ","
- Hex value <FF> will be used instead of "," in some special indications

e.g.

1. Received "1234567890" from mobile phone via SPP profile


```
>> +SPPDATA=10,1234567890
```
2. Call number "10086" use a mobile phone when HFP connected


```
>> +HFPSTAT=4
+HFPCID=10086
+HFPCIE=China Mobile
+HFPAUDIO=1
+HFPSTAT=6
```

1.6 Module Default Settings

Local Name (BR/EDR)	FSC-BT1006A-0002
Local Name (LE)	FSC-BT1006A-LE-0002
Pin Code	0000
Secure Simple Pairing Mode	On
Physical UART Baudrate	115200bps/8/N/1

2.Command Table

2.1 General Commands

2.1.1 AT Command Test

Format: AT
Response: OK
Description: Test the communication between HOST and Module after power on, UART baudrate changed and etc.
Example: AT command test << AT >> OK

2.1.2 Bluetooth Profile Selection <auto reboot>

Format: AT+PROFILE{=Param} Param: A base-10 representation of a bit field, default:171, for each bit: BIT[0] SPP (Serial Port Profile) BIT[1] GATT Server (Generic Attribute Profile) BIT[2] GATT Client (Generic Attribute Profile) BIT[3] HFP Sink (Hands-Free Profile) BIT[4] HFP Source (Hands-Free Profile) BIT[5] A2DP Sink (Advanced Audio Distribution Profile) BIT[6] A2DP Source (Advanced Audio Distribution Profile) BIT[7] AVRCP Controller (Audio/Video remote controller Profile) BIT[8] AVRCP Target (Audio/Video remote controller Profile) BIT[9] HID Keyboard (Human Interface Profile) BIT[10] PBAP Server (Phonebook Access Profile)
Response: +PROFILE=Param
Description: BT1006X supports SPP, GATT Server, GATT Client, HFP Sink, A2DP Sink, AVRCP Controller, HID Keyboard, PBAP Server

The default program does not support PBAP and HID Keyboard.

Example: Read current profile selection

```
>> AT+PROFILE
<< +PROFILE=171
<< OK
```

Example: Only Enable A2DP SINK,AVRCP Controller,

```
>> AT+PROFILE=160
<< OK
```

2.1.3 Read Firmware Version

Format: AT+VER

Response: +VER=Param

Param: Firmware version (26 Bytes ASCII)

Example: Read module's firmware version

```
<< AT+VER
>> +VER=FSC-BT100X,V1.0.0,20160120
>> OK
```

2.1.4 Read BR/EDR MAC Address

Format: AT+ADDR

Response: +ADDR=Param

Param: Module's BR/EDR MAC address (12 Bytes ASCII)

Example: Read Module's BR/EDR MAC address

```
<< AT+ADDR
>> +ADDR=DC0D30123456
>> OK
```

2.1.5 Read BLE MAC Address

Format: AT+LEADDR
Response: +LEADDR=Param Param: Module's LE MAC address (12 Bytes ASCII)

2.1.6 Read/Write BR/EDR Local Name

Format: AT+NAME {=Param1{, Param2}} Param1: BR/EDR local name (1~31 Bytes ASCII, default: FSC-BT1006A-0002) Param2: MAC address suffix (0/1, default:1) (0) Disable suffix (1) Enable suffix "-XXXX" (lower 4 bytes of MAC address) after local name
Response: +NAME=Param
Description: Write local name if parameter existence, otherwise read current local name
Example: Read current BR/EDR local name <pre><< AT+NAME >> +NAME=Feasycom >> OK</pre> Example: Change module's BR/EDR local name to "ABC" <pre><< AT+NAME=ABC >> OK</pre> Example: Change module's BR/EDR local name to "ABC" and enable suffix <pre><< AT+NAME=ABC,1 >> OK</pre>

2.1.7 Read/Write BLE Local Name

Format: AT+LENAME {=Param1{, Param2}} Param1: BLE local name (1~25 Bytes ASCII, default: FSC-BT1006A-LE-0002) Param2: MAC address suffix (0/1, default:1) (0) Disable suffix
--

(1) Enable suffix “-XXXX” (lower 4 bytes of MAC address) after local name

Response: +LENAM=Param

2.1.8 Read/Write BLE Random Address Configuration <need reboot>

Format: AT+LECFG {=Param}
 Param1: BLE Random address enable(0/1, default:1)
 (0) Disable
 (1) Enable

Response: +LECFG=Param

2.1.9 Read/Write UART Baudrate

Format: AT+BAUD{=Param}
 Param: Baudrate (9600/19200/38400/57600/115200/230400/460800/921600, default:115200)

Response: +BAUD=Param

Description: Module’s baudrate will be changed immediately after received this command

2.1.10 Read/Write Pin Code

Format: AT+PIN{=Param}
 Param: Pin code (4~15 Bytes ASCII, default:0000)

Response: +PIN=Param

Example: Read module’s pin code

```
<< AT+PIN
>> +PIN=0000
>> OK
```

Example: Change module’s pin code to “12345678”

```
<< AT+PIN=12345678
>> OK
```

2.1.11 Turn On/Off Secure Simple Pairing <need reboot>

Format: AT+SSP{=Param}

Param: Simple pairing (0/1, default:1)

(0) Turn off

(1) Turn on

Response: +SSP=Param

Description: Pin code input will be bypassed if simple pairing is on in pairing procedure

2.1.12 Read/Write Class Of Device <need reboot>

Format: AT+COD{=Param}

Param: Class of device (6 bytes ASCII, default:240404 Handsfree device)

Response: +COD=Param

2.1.13 Read/Clear Paired Record

Format: AT+PLIST{=Param}

Param:(0/(1~8)/12 Bytes MAC address)

(0) Clear all paired record

(1~8) Clear specific paired record with index

(MAC) Clear specific paired record with MAC address

Response1: +PLIST=Param1, Param2{, Param3}

Param1: (1~8) Paired device's index

Param2: (MAC) Paired device's MAC address

Param3: (UTF8) Paired device's name

Response2: +PLIST=E: End of the paired record

Example: Read module's paired record

```

<< AT+PLIST
>> +PLIST=1,1C5CF226D773, iPhone
    +PLIST=2, A0BC30075421, Samsung S8
    +PLIST=E
>> OK
  
```

Example: Clear module's paired record

```

<< AT+PLIST=0
>> OK
  
```

2.1.14 Turn On/Off Throughput Mode<need reboot>

Format: AT+TPMODE{=Param}

Param: Throughput mode (0/1, default:0)

(0) Turn Off

(1) Turn On

Response: +TPMODE=Param

Description: When SPP/GATT profile connected and throughput mode is on, the AT command will be de-active, every byte received via physical UART will be sent to air, vice visa

Example: Read current throughput mode

```

<< AT+TPMODE
>> +TPMODE=1
>> OK
  
```

Example: Turn off throughput mode

```

<< AT+TPMODE=0
>> OK
  
```

2.1.15 Read Module States

Format: AT+STAT

Response: +STAT=Param1, Param2, Param3, Param4, Param5, Param6, Param7, Param8, Param9

Param1: DEVSTAT

Param2: SPPSTAT

Param3: GATTSTAT
 Param4: HFPSTAT
 Param5: A2DPSTAT
 Param6: PEERSTAT
 Param7: AVRCPSTAT
 Param8: HIDSTAT
 Param9: PBSTAT

Description: Refer to chapter 3 for state description, state may have different meanings according to profile selection

2.1.16 Turn On/Off Power On Auto Reconnect <need reboot>

Format: AT+AUTOCONN{=Param}
 Param: Option (0~15, default:3)
 (0) Turn Off
 (1-15) Turn on and reconnect times

Response: +AUTOCONN=Param

Description: Module will attempt to connect last device after power on if set

2.1.17 Scan Nearby Devices

Format: AT+SCAN {=Param}
 Param1:(0~1)
 (0) Stop scan
 (1) Scan nearby BR/EDR devices

Description: Refer to Chapter 3 for format description of scan result when in A2DP Slave mode.

2.1.18 Speaker Volume Setting

Format: AT+SPKVOL{=Param}
 Param: ('+'/'-')

Response: +SPKVOL =Param

Example: Read current speaker volume

<< AT+SPKVOL

>> +SPKVOL=14

Example: Increase audio speaker volume

<< AT+SPKVOL=+

>> OK

2.1.19 I2S/PCM Format Configuration <need reboot>

Format: +I2SCFG{=Param}

Param: A base-10 representation of a bit field, default:0, for each bit:

BIT[0] 0: Disable I2S/PCM for audio input/output

1: Enable I2S/PCM for audio input/output

BIT[1] 0: I2S/PCM master role

1: I2S/PCM slave role

BIT[2] 0: 48000Hz sample rate

1: 44100Hz sample rate

BIT[3-4] 00: I2S Philips standard format

BIT[5-6] 00: 16-bit resolution

01: 24-bit resolution

10: 32-bit resolution

Example: Read current I2S/PCM configuration

<< AT+I2SCFG

>> +I2SCFG=0

Example: Set I2S/PCM configuration to: I2S master, 32-bit resolution,48kHz.

I2S LRCLK: 48000Hz

I2S BCLK: 3.072MHz (48000Hz * 32bit * 2Stereo)

<< AT+I2SCFG=65

>> OK

2.1.20 I2S Channel Setting < need reboot >

Format: AT+I2SCHAN{=Param}

Param: (0/1, default:0)

(0) I2S Channel to Hardware I2S1

(1) I2S Channel to Hardware I2S2
Response: + I2SCHAN =Param
Description: I2S2 only supports output

2.1.21 Release All Connections

Format: AT+DSCA
Description: Module release all Bluetooth connections with remote device

2.1.22 Soft Reboot

Format: AT+REBOOT
Description: Module release all Bluetooth connections with remote device then reboot

2.1.23 Restore Factory Settings

Format: AT+RESTORE
Description: Module restore all factory settings then reboot

2.1.24 Enable Module

Format: AT+BTEN {=Param} Param: (0~1) (0) Bluetooth disable (1) Bluetooth enable
Description: Disconnect all device connected and put module enter unconnectable and undiscoverable state .Always effective even reboot.

2.1.25 Enter Pairing Mode

<p>Format: AT+PAIR{=Param} Param: (0~1) (0) Exit Pairing Mode (1) Enter Pairing Mode</p>
<p>Description: put module enter or quit connectable and discoverable state.</p>

2.1.26 Enable Print Log

<p>Format: AT+PRINT{=Param} Param: (0~1) (0) Disable (1) Enable</p>
<p>Description: Enable module print the log(including states of profiles) to uart.</p>

2.1.27 Audio Active PIO Delay Time Configuration

<p>Format: AT+MUTEDDELAY{=Param} Param: (0~60) Delay time = (Param * 50)ms</p>
<p>Description: The param is used to eliminate the “popo” noise when the audio just established.</p>

2.1.28 LineIn Configuration <need reboot>

<p>Format: AT+LINECFG{=Param} Param: (0~1) (0) Disable LineIn (1) Enable LineIn</p>
<p>Description: Bluetooth input source from linein</p>

2.2 HFP Commands

2.2.1 Read HFP State

Format: AT+HFPSTAT
Response: +HFPSTAT=Param Param:(0~6) (0) Unsupported (1) Standby (2) Connecting (3) Connected (4) Outgoing call (5) Incoming call (6) Active call

2.2.2 Establish HFP Connection

Format: AT+HFPCONN{=Param} Param: MAC address of target device (12 Bytes ASCII)
Description: Module will reconnect to last HFP device if parameter not exist
Example: Connect to last HFP device << AT+HFPCONN >> OK Example2: Connect to specific HFP device with MAC address << AT+HFPCONN=1C5CF226D773 >> OK

2.2.3 Release HFP Connection

Format: AT+HFPCONN
Description: Release current HFP connection with remote device

2.2.4 Dial/Redial Phone Number

<p>Format: AT+HFPDIAL{=Param} Param: Phone number (1~25 Bytes ASCII)</p>
<p>Description: Dial specific number if parameter existence, otherwise redial</p>
<p>Example: Redial << AT+HFPDIAL >> OK Example: Dial number "075527924639" << AT+HFPDIAL=075527924639 >> OK</p>

2.2.5 Send DTMF code

<p>Format: AT+HFPDTMF=Param Param: DTMF code (0~9/#/*)</p>
<p>Example: Send DTMF code "#" while talking << AT+HFPDTMF=# >> OK</p>

2.2.6 Pick Up Incoming Call

<p>Format: AT+HFPANSW</p>
<p>Description: Pick up an incoming call</p>

2.2.7 Reject/Hung up Call

<p>Format: AT+HFPCHUP</p>
<p>Description: Reject incoming call or hung up outgoing/active call</p>

2.2.8 Transfer Voice Audio

Format: AT+HFPADTS{=Param}

Param: Transfer direction (0/1)

(0) Transfer voice audio from module to remote device

(1) Transfer voice audio from remote device to module

Description: Transfer voice audio between module and remote device by default if no parameter existence

2.2.9 Mute Mic

Format: AT+MUTEMIC{=Param}

Param: mute mic(0/1)

(0) unmute

(1) mute

Description: mute mic when call active

2.3.0 Start/Stop Voice Recognition of Remote Device

Format: AT+HFPVR=Param

Param: On/off (0/1)

(0) Stop

(1) Start

Description: Start/Stop Voice Recognition of Remote Device (such as Siri for iOS devices)

2.3 A2DP/AVRCP Commands

2.3.1 Read A2DP State

Format: AT+A2DPSTAT

Response: +A2DPSTAT=Param

Param:(0~4)

- (0) Unsupported
- (1) Standby
- (2) Connecting
- (3) Connected
- (4) Streaming

2.3.2 Establish A2DP Connection

Format: AT+A2DPCONN{=Param}

Param: MAC address of target device (12 Bytes ASCII)

Description: Module will reconnect to last A2DP device if no parameter exist

Example: Connect to last A2DP device

<< AT+A2DPCONN

>> OK

Example2: Connect to specific A2DP device with MAC address

<< AT+A2DPCONN=1C5CF226D773

>> OK

2.3.3 Release A2DP Connection

Format: AT+A2DPDISC

Description: Release current A2DP connection with remote device

2.3.4 Read A2DP Decoder

Format: AT+A2DPDEC

Response: +A2DPDEC=Param

Param:(0~7)

- (0) INVALID
- (1) SBC

- (2) MP3
- (3) AAC
- (4) FASTSTREAM
- (5) APTX
- (6) APTX-Sprint
- (7) APTX-HD
- (8) APTX-LL

2.3.5 Read/Write AVRCP Configuration

Format: AT+AVRCPCFG{=Param}

Param: A base-10 representation of a bit field, default:9, for each bit:

BIT[0] Auto get track ID3 information (title, artist, album) on track changed.default:1

BIT[1-3] Auto get track state (play progress) if value > 0. default:5(second)

Example: Read AVRCP configuration

```
<< AT+AVRCPCFG
>> +AVRCPCFG=9
OK
```

Example: Get track play progress every 1 second

```
<< AT+AVRCPCFG=3
>> OK
```

Description: Refer to Chapter 3 for indication format of track information and track state

2.3.6 Track Play/Pause

Format: AT+PLAYPAUSE

Description: Send play or pause command to remote media player according to current play status

2.3.7 Track Play

Format: AT+PLAY

Description: Send play command to remote media player

2.3.8 Track Pause

Format: AT+PAUSE

Description: Send pause command to remote media player

2.3.9 Track Stop

Format: AT+STOP

Description: Send stop command to remote media player

2.3.10 Track Forward

Format: AT+FORWARD

Description: Send forward command to remote media player

2.3.11 Track Backward

Format: AT+BACKWARD

Description: Send backward command to remote media player

2.3.12 Track FastForward

Format: AT+FFDW=Param

Param: (0/1)

(0) Fast Forward Release

(1) Fast Forward Press

Description: Send fast forward command to remote media player

2.3.13 Track Rewind

Format: AT+RWD=Param

Param: (0/1)

- (0) Rewind Release
- (1) Rewind Press

Description: Send rewind command to remote media player

2.4 TWS Commands

2.4.1 Read TWS State

Format: AT+PEERSTAT

Response: +PEERSTAT=Param

Param:(0~4)

- (0) Unsupported
- (1) Standby
- (2) Connecting
- (3) Connected
- (4) Streaming

2.4.2 TWS Configuration <need reboot>

Format: AT+PEERCFG{=Param}

Param: (0/1)

- (0) Disable Peer TWS
- (1) Enable Peer TWS

2.4.3 Pair TWS Device

<p>Format: AT+PEERINQ=Param Param: (0/1) (0) Stop pair tws device (1) Start pair tws device</p>
<p>Description: If set, disconnect all established connections and pair another TWS peer device</p>

2.4.4 Read/Clear TWS Paired Record

<p>Format: AT+PEERDEV{=Param } Param:(0) Clear tws paired record</p>
<p>Response1: +PEERDEV=Param1, Param2 Param1: (0/1) Paired device's role(0-slave, 1-master) Param2: (MAC) Paired device's MAC address</p>
<p>Example: Read module's tws paired record << AT+PEERDEV >> +PEERDEV=1,DC0D30000002 >> OK</p> <p>Example: Clear module's tws paired record << AT+PEERDEV=0 >> OK</p>
<p>Description:Set the module into TWS slave role and reboot automatically after cleared.</p>

2.4.5 Release TWS Connection

<p>Format: AT+PEERDISC</p>
<p>Description: Release current TWS connection with remote device</p>

2.5 Phonebook Access Commands

2.5.1 Download Phonebook

<p>Format: AT+PBDOWN=Param1{, Param2}</p> <p>Param1: Phonebook type (0~5)</p> <ul style="list-style-type: none"> (0) Phonebook (SIM Storage) (1) Phonebook (Phone Storage) (2) Received call log (3) Dialed call log (4) Missed call log (5) All call log <p>Param2: Max items (1~65535, default:3000 for phonebook; 50 for call log)</p>
<p>Response: +PBDATA=Param1<FF>Param2<FF>Param3 {<FF>Param4}</p> <p>Param: Refer to Chapter 3 for format description of received phonebook data</p>

2.6 Bluetooth Serial Commands (BR/EDR SPP)

2.6.1 Read SPP State

<p>Format: AT+SPPSTAT</p>
<p>Response: +SPPSTAT=Param</p> <p>Param: Refer to Chapter 3 for state description</p>

2.6.2 Establish SPP Connection

<p>Format: AT+SPPCONN=Param</p> <p>Param: MAC address of target device (12 Bytes ASCII)</p>
<p>Description: If target device is mobile phone, mobile phone must have initialized a RFCOMM service before this</p>

2.6.3 Release SPP Connection

Format: AT+SPPDISC
Description: Release current SPP connection with remote device

2.6.4 Send Data Via SPP

Format: AT+SPPSEND=Param1, Param2 Param1: Payload length (1~236) Param2: Payload (1~236Bytes UTF8)
Description: If throughput mode is on, this command is de-active
Example: Send data "1234567890" to remote device via SPP << AT+SPPSEND=10,1234567890 >> OK

2.7 Bluetooth Serial Commands (LE GATT)

2.7.1 Read GATT State

Format: AT+GATTSTAT
Response: +GATTSTAT=Param Param: Refer to Chapter 3 for state description

2.7.2 Release GATT Connection

Format: AT+GATTDISC
Description: Release current GATT connection with remote device

2.7.3 Send Data Via GATT

<p>Format: AT+GATTSEND=Param1, Param2 Param1: Payload length (1~100) Param2: Payload (1~100 Bytes UTF8)</p>
<p>Description: If throughput mode is on, this command is de-active</p>
<p>Example: Send data “1234567890” to remote device via GATT << AT+GATTSEND=10,1234567890 >> OK</p>

3. Indication Table

3.1 General Indications

3.1.1 Device State

<p>Format: +DEVSTAT=Param Param: A base-10 representation of a bit field, for each bit: BIT[0] 0: Power Off; 1: Power On BIT[1] 0: BR/EDR Non Discoverable; 1: BR/EDR Discoverable BIT[2] 0: BLE Non Advertising; 1: BLE Advertising BIT[3] 0: BR/EDR Non Scanning; 1: BR/EDR Scanning BIT[4] 0: BLE Non Scanning; 1: BLE Scanning</p>
<p>Example: Module is power on, discoverable and advertising >> +DEVSTAT=7</p>

3.1.2 Scan Result

<p>Format: +SCAN =Param1<FF>Param2<FF>Param3<FF>Param4<FF>Param5<FF>Param6 Param1: Index (1~8) Param2: Device address type (0~2) (0)LE public address</p>

<p>(1)LE random address (2)BR/EDR address Param3: MAC address (12 Bytes ASCII) Param4: RSSI (-255 ~ 0) Param5: Size of Param6 if exist Param6: Device Name for BR/EDR devices or advertising data for LE devices</p>
<p>Description: Param5/Param6 may not exist if remote device out of distance</p>
<p>Example: Scan BR/EDR nearby devices in 6.4s</p> <pre><< AT+SCAN=1,5 >> OK +SCAN=1<FF>2<FF>DC0D30000003<FF>-32<FF>8<FF>Feasycom +SCAN=2<FF>2<FF>DC0D30000044<FF>-64<FF>8<FF>Feasycom_1234 +SCAN=3<FF>2<FF>DC0D30000097<FF>-47<FF>8<FF> TESTHID</pre>

3.1.3 Paired Success

<p>Format: +PAIRED=Param Param: MAC address (12 Bytes ASCII) of current paired device</p>

3.2 HFP Indications

3.2.1 HFP State

<p>Format: +HFPSTAT=Param Param:(0~6)</p> <ul style="list-style-type: none"> (0) Unsupported (1) Standby (2) Connecting (3) Connected (4) Outgoing call (5) Incoming call (6) Active call
--

3.2.2 HFP Device Information

<p>Format: +HFPDEV=Param1,Param2 Param1: (12 Bytes ASCII), Remote device's MAC address of current HFP connection Param2: (UTF8), Remote device's name of current HFP connection</p>
<p>Example: HFP connect success with device >> +HFPDEV=1C5CF226D774,iPhone</p>

3.2.3 Incoming/Outgoing Call Number

<p>Format: +HFPCID=Param Param:(1~25 Bytes ASCII), Call number</p>
<p>Example: Dial number 10086 << AT+HFPDIAL=10086 >> +HFPSTAT=4 +HFPCID=10086 +HFPCIE=China Mobile +HFPAUDIO=1</p> <p>Example: Incoming call with number 13265463800 >> +HFPSTAT=5 +HFPCID=13265463800 +HFPCIE=Jerry +HFPAUDIO=1</p>

3.2.4 Incoming/Outgoing Call Name

<p>Format: +HFPCIE=Param Param:(UTF8), Call name</p>
<p>Description: Not every mobile phone support this indication</p>

3.2.5 HFP Voice Audio State

<p>Format: +HFPAUDIO=Param</p>

Param:(0/1)
(0) HFP voice audio disconnected, audio input/output routed to remote device
(1) HFP voice audio connected, audio input/output routed to module

3.2.6 HFP Device Network Signal Strength

Format: +HFPSIG=Param
Param:(0~5) Network signal strength of remote device

3.2.7 HFP Device Network Operator Selection

Format: +HFPNET=Param
Param:(UTF8) Network operator selection of remote device

3.2.8 HFP Device Roaming State

Format: +HFPROAM=Param
Param:(0/1) Roaming state of remote device

3.2.9 HFP Device Battery Level

Format: +HFPBATT=Param
Param:(0~5) Battery level of remote device

3.3 A2DP/AVRCP Indications

3.3.1 A2DP State

Format: +A2DPSTAT=Param
Param:(0~4)
(0) Unsupported
(1) Standby
(2) Connecting

- (3) Connected
- (4) Streaming

3.3.2 A2DP Device Information

Format: +A2DPDEV=Param

Param: (12 Bytes ASCII), Remote device's MAC address of current A2DP connection

3.3.3 AVRCP State

Format: +AVRCPSTAT=Param

Param:(0~3)

- (0) Unsupported
- (1) Standby
- (2) Connecting
- (3) Connected

3.3.4 Media Player State

Format: +PLAYSTAT=Param

Param:(0~4)

- (0) Stopped
- (1) Playing
- (2) Paused
- (3) Fast Forwarding
- (4) Fast Rewinding

3.3.5 Media Player Play Progress

Format: +TRACKSTAT=Param1, Param2, Param3

Param1:(0~4), Media Player State

Param2:(Decimal ASCII), Elapsed time of current track in second

Param3:(Decimal ASCII), Total time of current track in second

Example: Read media player play progress every 3s


```
<< AT+AVRCPCFG=7
>> +TRACKSTAT=1,142000,248000
    +TRACKSTAT=1,145000,248000
    +TRACKSTAT=1,148000,248000
```

3.3.6 Media Track Information

Format: +TRACKINFO=Param1 <FF> Param2 <FF> Param3

Param1: title

Param2: artist

Param3: album

Example: Phone playing song "Creep-Radio Head"

```
>> +TRACKINFO=Creep <FF> Radiohead <FF> Pablo Honey
```

3.4 Phonebook Access Indications

3.4.1 PBAPC State

Format: +PBSTAT=Param

Param:(0~4)

(0) Unsupported

(1) Standby

(2) Connecting

(3) Connected

(4) Downloading

3.4.2 PB Entries Of Remote Devices

Format: +PBCNT=Param

Param: Phonebook entries of remote device

3.4.3 Received Phonebook Data

<p>Format1: +PBDATA=Param1 <FF> Param2 xFF \xParam3 {xFF Param4}</p> <p>Param1: Type</p> <ul style="list-style-type: none"> (0) Phonebook (SIM Storage) (1) Phonebook (Phone Storage) (2) Received call log (3) Dialed call log (4) Missed call log <p>Param2: (UTF8), Name</p> <p>Param3: (ASCII), Number</p> <p>Param4: (15 Bytes ASCII), Call time</p> <p>Format:</p> <p>Year(4Bytes)Month(2Bytes)Day(2Bytes) T(1Byte)Hour(2Bytes) Minute(2Bytes)Second(2Bytes). e.g. 20161012T152826 represents 2016/10/12/15/28/26</p> <p>Format2: +PBDATA=E: Download complete</p>
<p>Description: Call time may not exist for some mobile phones</p>
<p>Example: Download all phonebook</p> <pre><< AT+PBDOWN=1 >> +PBCNT=234 +PBDATA=1 <FF> Jack <FF> 18219146201 +PBDATA=1 <FF> kenan <FF> 8613771972680 +PBDATA=E</pre> <p>Example: Download 10 dialed call log</p> <pre><< AT+PBDOWN=3,10 >> +PBDATA=3 <FF> China Mobile <FF> 10086 <FF> 20171013T103516 +PBDATA=3 <FF> Jerry <FF> 18688967507 <FF> 20171012T152826 +PBDATA=E</pre>
<p>Description: See MSC example in 4.3</p>

3.5 Bluetooth Serial Indications

3.5.1 SPP State

Format: +SPPSTAT=Param

Param:(0~3)

- (0) Unsupported
- (1) Standby
- (2) Connecting
- (3) Connected

3.5.2 GATT State

Format: +GATTSTAT=Param

Param:(0~3)

- (0) Unsupported
- (1) Standby
- (2) Connecting
- (3) Connected

3.5.3 SPP Device Information

Format: +SPPDEV=Param

Param: (12 Bytes ASCII), Remote device's MAC address of current SPP connection

3.5.4 GATT Device Information

Format: +GATTDEV=Param

Param: (12 Bytes ASCII), Remote device's MAC address of current GATT connection

3.5.5 SPP Received Data

Format: +SPPDATA=Param1, Param2

Param1: Payload length

Param2: Payload
Description: If throughput mode is on, only Param2 will be present
Example: Received data "1234567890" from remote device via SPP << +SPPDATA=10,1234567890

3.5.6 GATT Received Data

Format: +GATTDATA=Param1, Param2 Param1: Payload length Param2: Payload
Description: If throughput mode is on, only Param2 will be present
Example: Received data "1234567890" from remote device via GATT << +GATTDATA=10,1234567890

3.6 GPIO Indications

3.6.1 LED Pin


LED0(Output)	
Low Level	Initializing
Blink in 1Hz	Ready to connecting
High Level	Connected

3.6.2 State Pin


LED1(Output)	
Low Level	SPP/GATT Disconnected
High Level	SPP/GATT Connected

4.Example Message Sequence Charts

4.1MSC for profiles initializing and device scanning



4.2MSC for profiles connection and basic operations



4.3MSC for Phonebook/Contact photo downloading

