

FSC-DB103(FSC-BT802) User Guide V1.3

4.FSC-BT802 Module

11. SPI Testing Port

1.USB-To-UART Port (Micro)
Using this port to send AT Commands or to Send/Receive Data

2. USB Testing Port (Micro)

3. Battery Powering Port

6. When powered on, LED0 flash slowly;

When connection built, LED0 will be steadily on.

10. Select Pin :

In Default : I2S,
Short-Out : SPI

5.PLAY/PAUSE POWER ON/OFF : PLAY/PAUSE POWER ON/OFF : Long press for 2 seconds to Power On, short press to Pause
VOL+/NEXT : Short press to Volume+, long press to switch to Next Song
VOL-/BACK : Short press to Volume-, long press to switch to Last Song

7. (SPK) Audio Output

8. (MIC) Audio Input

9. (LINE IN) Voice Input
3.5mm TRS (LINE IN) cable ONLY

